


Data Visualization for Analysis of the NCNR Cold Neutron Source

Max Carlson
Nuclear Engineering
Georgia Institute of Technology




NCNR



NBSR


- * Research reactor
- * 20 MW
- * Thermal neutron flux on order of $10^{14} \text{ n cm}^{-2} \text{ s}^{-1}$
- * Cold neutrons useful in experiments
 - * Longer wavelength
 - * Probe larger structures, smaller energy changes

Cold vs. Thermal Neutrons



Moderator Temperature (K)	Most Probable Energy (eV)	Wavelength (Angstroms)
315	.030	1.6
20	.002	6.4

Cold Neutron Source



Refrigerator

- * System to cool helium to 14K
- * Rated for 3500W heat removal
- * Keeps cold source cold!
- * Many active components need monitoring

PLC

- * Programmable Logic Controller
- * Operates cold source and refrigerator without human intervention
- * Checks all sensors and controls valves
- * Sends out alarm if necessary

Troubleshooting


- * Need logs to find problem source
- * RSView can keep log of sensor readings
 - * DBF format not easily accessible
- * Default Trends viewer is limited
 - * Pre-set time scale
 - * Pre-set Y Axis scale
 - * Pre-set sensor display
 - * Cannot export data


CSPlot

- * Parses DBF file format
- * Fully interactive chart
 - * Mouse drag to set X and Y axes properties
 - * Mouse scroll to zoom in
 - * Series tracing
- * Adding arbitrary sensors to chart
- * Export of chart to Excel file
- * Save reference to chart for record-keeping

CSPlot: Demo

- * Reactor rundown
- * Vacuum gauge noise reduction
- * Used by cold source team to diagnose problems and evaluate efficiency of solutions






CSScreens

- * Allows monitoring of cold source via network
- * Schematic view
- * Matches layout of existing software
- * Read-only

CSScreens: Demo

- * Useful in checking the cold source is operational
- * Currently used by reactor operators and cold source team



Vacuum Pump

- * Good vacuum is critical to cooling system
- * Turbomolecular pumps have failed before
 - * Overheating
 - * Power surges
- * Pump status -> PLC
 - * Seal off failed vacuum pump

Vacuum Pump

- * Inputs: Error (digital), Speed (analog)
- * Outputs: On (digital), Control (digital)
- * Wire connection to PLC
- * Logic code added to PLC
- * Control buttons added to RSView
- * Prototype successful
 - * Installation requires reactor shutdown

Acknowledgments

- * Julie Borchers
- * Michael Middleton
- * Dennis Nester
- * Mike Rowe
- * Robert Williams